

## ASSEMBLY INSTRUCTIONS

### ITEM#L81008


#### A: TABLE LAMP

1. UNWRAP ALL PARTS. CAREFULLY REMOVE ALL PARTS FROM PACKING MATERIAL .
2. SCREW SOCKET ASSEMBLY ONTO LAMP BODY. BE CAREFUL NOT TO TWIST POWER CORD .
3. PLACE HARP ONTO SADDLE.
4. PLACE SHADE ONTO HARP AND TIGHTEN FINIAL.
5. PLACE USE MAX 3-WAY100W TYPE "A" BULB (BULB NOT INCLUDED)

#### IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK.THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY.IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN.

NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED.DO NOT ALTER THE PLUG.



#### B :FLOOR LAMP

1. UNWRAP ALL PARTS. CAREFULLY REMOVE ALL PARTS FROM PACKING MATERIAL .
- 2:SCREW TUBE 1 ONTO BASE .
- 3:SCREW TUBE 2 ONTO TUBE 1 .
- 4:SCREW TUBE 3 ONTO TUBE 2.
- 5: FASTEN SOCKET ASSEMBLY ONTO TUBE 3. BE CAREFUL NOT TO TWIST POWER CORD .
- 6: PLACE HARP ONTO SADDLE.
- 7: PLACE SHADE ONTO HARP AND TIGHTEN FINIAL.
- 8.UTILISER UNE AMPOULE 3-WAY 100 WATTS MARCHE/ARRÊT SUR LA LAMPE ( AMPOULE NON INCLUSE ) .

#### IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK.THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY.IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN.

NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED.DO NOT ALTER THE PLUG.

